

Installation Instruction for Skylight Screens

Skylight can be brittle. Do not touch Dome, pyramid, or Glazing. Wear Gloves when handling screen. Wear Safety Glasses when installing FallGuard Rails.

INSTALLATION PROCEDURE::

1. Center FallGuard Rail onto Length Side of Skylight Retaining Frame (Figure 1).
2. Secure the FallGuard Rail onto skylight retaining frame with specially provided galvanized steel hex washer self-drilling screws through the pre-punched holes. (Figure 1& 2) (Number of screw varies to dimensions).
3. Center the screen over the skylight and install the Bases of the Screens into the Rail Notch openings (Figure 3).
4. Install the furnished stainless Steel Clips by snapping them in place on the rail notches. Start on the ends and space about ~ 12–18” apart (**ONE BAG PER FALLGUARD SCREEN!! CLIPS DO NOT NEED TO BE ON ALL NOTCHES**). **# Clips/2 = 1 Rail**. (Figure 4).

