

WARNING: DO NOT PLACE BODYWEIGHT ON SKYLIGHT DURING INSTALLATION. USE EXTREME CAUTION WHEN INSTALLING THE SKYLIGHT SCREENS. WEAR GLOVES WHEN HANDLING SCREEN AND WEAR SAFETY GLASSES WHEN USING DRILL.

INSTALLATION PROCEDURE:

1. INSTALL THE RAILS SO THAT SCREEN HOLDING NOTCHES IN A LOWER POSITION (OPENING FACE UPWARD TOWARD ROOF PEAK) (FIGURE 1).
2. ATTACH THE FLANGE OF THE TSSR RAILS TO THE OUTSIDE OF THE STANDING SEAM WITH THE FURNISH HEX WASHER SCREWS HEAD SELF-DRILLING SCREWS. (FIGURE 2).
3. SLIDE THE SKYLIGHT SCREEN INTO THE NOTCHES ON THE ATTACHED RAILS (FIGURE 3).

